

MATERIALS:

- 25" of 1x6
- 25" of 1x8
- 9" of 1x2
- 1 – 1x4x6'
- 1 ¼" Pocket Hole Screws
- 1 ¼" Wood Screws
- 1 ¼" Brad Nails
- Wood Glue

CUT LIST:


- 1 – 1x6 @ 25" (stemware hanger)
- 1 – 1x8 @ 25" (back)
- 2 – 1x2 @ 4 ¼" (sides)
- 2 – 1x4 @ 25" (ledge and front)
- 2 – 1x4 @ 2 ¾" (sides)

TOOLS:

- Tape Measure
- Pencil
- Circular Saw
- Jigsaw
- Safety Glasses
- Speed Square
- Drill with Countersink Drill Bit
- Kreg Jig
- Brad Nailer or Hammer
- Hearing Protection


STEP 1

Cut out the stemware slats with a jigsaw, as shown.




STEP 2

Attach back with 3/4" pocket holes and 1 1/4" pocket hole screws and glue.




STEP 3


Attach 1x2 sides with 1 ¼" pocket hole screws. Also, attach 1x2 sides to the stemware board with 1 ¼" brad nails.

STEP 3 - ATTACH 1x2 SIDES >>>**STEP 4**

Attach ledge with ¾" pocket holes and 1 ¼" pocket hole screws and glue. Alternately, attach ledge with 1 ¼" brad nails.



STEP 5
Attach sides with $\frac{3}{4}$ " pocket holes and $1 \frac{1}{4}$ " pocket hole screws and glue.



STEP 6

Attach front board by countersinking 1 1/4" wood screws as shown.

STEP 6 - ATTACH FRONT >>>

