

MATERIALS:

(3) 2 x 2 x 8 Ft. Boards

(3) 1 x 12 x 6 Ft. Boards

(3) 1 x 2 x 6 Ft. Boards

2 1/2-inch Pocket Screws

1 1/4-inch Brad Nails

(18) Metal L Brackets

Wood Filler

Wood Glue

TOOLS:

Tape Measure

Pencil

Carpenter's Square

Cordless Drill/Driver

Circular Saw

Pocket Hole Jig

Brad Nailer or Hammer


Safety Glasses

Hearing Protection

Dust Mask


CUT LIST:

- (3) 2x2 @ 24 ½ inches (back legs)
- (3) 2x2 @ 23 inches (front legs)
- (9) 2x2 @ 11 ¼ inches (aprons)
- (3) 1x12 @ 58 inches (shelves)
- (3) 1x2 @ 58 inches (shelf back lip)




STEP 1 – BUILD THREE BASES

Measure, mark, and cut 2x2 boards to length. Drill 1 %-inch pocket holes into the ends of the aprons and attach them to the legs with 2 %-inch pocket screws and wood glue. Make three of these bases.



STEP 2 – BUILD THREE SHELVES

Measure, mark, and cut 1x12 and 1x2 boards to length. Attach the 1x2 to the 1x12 as shown with 1 ¼-inch brad nails and wood glue. Make three of these shelves.



STEP 3 – ATTACH SHELVES TO THE BASE

Position the shelves along the bases with a 5-inch overhang on each side and secure with metal L brackets underneath. Alternately, you can use metal figure 8 table fasteners or Z-clips.

Fill screw and nail holes with wood putty, sand, stain and/or paint, and finish as desired.