


EVELYN MAKEUP VANITY



Jen
WOODHOUSE

MATERIALS

- ☐ (3) 2 x 2 x 8 Ft. Boards
- ☐ (1) 1 x 6 x 4 Ft. Board
- ☐ (2) 1 x 2 x 8 Ft. Boards
- ☐ (1) 2 x 4 Ft. Sheet of $\frac{3}{4}$ -inch Plywood
- ☐ (2) 1 x 3 x 8 Ft. Boards
- ☐ (1) 1 x 4 x 4 Ft. Board
- ☐ (1) 2 x 4 Ft. Sheet of $\frac{1}{4}$ -inch Plywood
- ☐ 2 $\frac{1}{2}$ -inch and 1 $\frac{1}{4}$ -inch Pocket Screws
- ☐ 2-inch and 1 $\frac{1}{4}$ -inch Wood Screws
- ☐ 1 $\frac{1}{4}$ -inch Brad Nails
- ☐ (1) Set of 18-inch Drawer Slides
- ☐ (2) Drawer Knobs


TOOLS

- ☐ Tape Measure
- ☐ Pencil
- ☐ Carpenter's Square
- ☐ Cordless Drill/Driver
- ☐ Circular Saw or Table Saw
- ☐ Pocket Hole Jig
- ☐ Brad Nailer or Hammer
- ☐ Safety Glasses
- ☐ Hearing Protection
- ☐ Dust Mask

CUT LIST

- | | |
|--|---|
| ☐ (4) 2x2 @ 29 ¼ inches (legs) | ☐ (1) ¾-inch plywood @ 42 inches x 23 inches (top) |
| ☐ (2) 1x6 @ 19 inches (sides) | ☐ (2) 1x3 @ 34 ½ inches (drawer front/back) |
| ☐ (2) 2x2 @ 19 inches (side stretchers) | ☐ (2) 1x3 @ 16 inches (drawer sides) |
| ☐ (3) 2x2 @ 37 inches (aprons and back stretcher) | ☐ (1) 1x3 @ 14 ½ inches (drawer divider) |
| ☐ (2) 1x2 @ 38 ½ inches (drawer supports) | ☐ (1) ¾-inch plywood @ 36 inches x 16 inches (drawer bottom) |
| ☐ (2) 1x2 @ 16 inches (drawer supports) | ☐ (1) 1x4 @ 36 ¾ inches (drawer face) |
| ☐ (2) 1x2 @ 19 inches (drawer slide supports) | |

FIG. 1




Jen
WOODHOUSE

STEP 1


Measure, mark, and cut 2x2 legs and side stretchers to length. Drill 1 ½-inch pocket holes into the ends of the side stretchers and attach them to the legs about 2 inches from the bottom with 2 ½-inch pocket screws and wood glue. Measure, mark, and cut 1x6 sides to length. Drill ¾-inch pocket holes into the ends of the 1x6 boards and attach them to the legs, flush to the exterior, with 1 ¼-inch pocket screws and wood glue.

FIG. 2




STEP 2

Measure, mark, and cut 2x2 supports to length. Drill 1 ½-inch pocket holes into the ends of these boards and construct the carcass as shown, with 2 ½-inch pocket screws and wood glue.


FIG. 3**STEP 3**

Measure, mark, and cut 1x2 boards to length. Drill $\frac{3}{4}$ -inch pocket holes into the ends and attach them as shown with 1 $\frac{1}{4}$ -inch pocket screws and wood glue.

FIG. 4**STEP 4**


Measure, mark, and cut 1x2 drawer slide supports to length. Attach to the sides with 1 ¼-inch brad nails and wood glue. Install the drawer slides according to manufacturer's directions. It will be easier to install the slides now, before you attach the top.

FIG. 5

**STEP 5**


Measure, mark, and cut plywood top to size. Position the top over the carcass so that there's a 1-inch overhang on the front and sides. The back edge should be flush to the back of the vanity. Pre-drill pilot holes and attach the top with 2-inch wood screws driven from underneath the 2x2 aprons.

FIG. 6A

*Jen*
WOODHOUSE**STEP 6**

Measure, mark, and cut drawer fronts, back, sides, and divider to length. Drill $\frac{3}{4}$ -inch pocket holes into the front and back pieces. Construct the drawer box with 1 $\frac{1}{4}$ -inch pocket screws and wood glue. Position the divider in the middle and secure with wood glue and 1 $\frac{1}{4}$ -inch brad nails. Measure, mark, and cut the $\frac{1}{4}$ -inch plywood bottom to size. Attach to the bottom of the drawer box with 1 $\frac{1}{4}$ -inch brad nails and wood glue.

FIG. 6B

**STEP 7**

Measure, mark, and cut drawer face to length. Optional: use a palm router to make a groove on the front, for the faux double drawer front. You can also use a circular saw or table saw to do this. Slide the drawer box into place on the drawer slides. Position and attach the drawer face to the drawer box with 1 ¼-inch wood screws. Install drawer knobs.

Sand, stain and/or paint, and finish as desired.